

# COMPENSATORI DI CORSA ASSIALE



## Compensatori di corsa assiali

Modello	Applicabile a:	Quadro in uscita (in)
TNA1-SA02-30	ENRZ-TU0R5R-S	3/8"
	ENRZ-TU001R-*	3/8"
	ENRZ-TU003R-*	3/8"
TNA1-SA05-35	ENRZ-TU004R-S	1/2"
	ENRZ-TU008R-*	1/2"
TNA1-SA20-45C	ENRZ-TU013R-*	5/8"
TNA1-SA20-45Z	ENRZ-TU020R-*	5/8"
TNA1-SA40-70	ENRZ-TU040R-S	1"
	ENRZ-TU060R-S	1"
TNA1-SA80-80	ENRZ-TU080R-S	1+1/4"
TNA1-SA150-50	ENRZ-TU150R-S	1+1/2"
TNA1-SA150-120	ENRZ-TU150R-S	1+1/2"

Suffisso\*: S per modelli dritti, O per modelli Offset

## Adattatori per compensatori

Modello	Quadro in uscita (in)
TNA1-AD01-01	3/8" - 3/8"
TNA1-AD05-01	1/2" - 1/2"
TNA1-AD05-02	1/2" - 3/8"
TNA1-AD20-01	5/8" - 5/8"
TNA1-AD20-02	5/8" - 1/2"
TNA1-AD20-03	5/8" - 3/4"
TNA1-AD40-01	1" - 1"
TNA1-AD40-02	1" - 3/4"
TNA1-AD80-01	1+1/4" - 1+1/4"
TNA1-AD80-02	1+1/4" - 1"
TNA1-AD150-01	1+1/2" - 1+1/2"
TNA1-AD150-02	1+1/2" - 1"