

SUPPORTI




Base Support
FS-52BS



Base Support
FS-74BS



Base Support
US-104BS



Column
FS-52C
FS-74C
FS-104C



Height adjuster
US-52HA
US-74HA
US-104HA




Parallel Support
FS-52PS
FS-74PS



Column Support
FS-52CS
FS-74CS
US-104CC



Swivel Support
FS-52SS
FS-74SS
US-W104SC



Modello	A	B	C	D	E	F	G	H	I	Macchina Applicabile
	mm									
FS-52	52	80	115	40	120	500	30	43	52	SFB - SRV2 - MSR2 - SSTR2
US-52										
FS-74	74	110	135	45	140	600	30	56	65	SRV3 - MSR3 - SSTR3 - STB
US-74										
FS-104	104	190	250	70	248	1000	38	77	95	SRV5 - MSR5 - SSTR5 - STC
US-104										