


SUPPORTI



Modello	A	B	C	D	E	F	G	H	I	J	K	L	Macchina Applicabile
	mm												
LC-52	30	50	70	6,5	52	95	60	14	35	8	64	80	SFB - SRV2 - MSR2 - SSTR2
LC-52H						135	100						
LC-68	45	80	100	9	68	116	70	15	45	10	80	100	SFC
LC-74	60	110	130	9	74	120	70	18	50	10	19	110	SRV3 - MSR3 - SSTR3 - STB
LC-74H						150	100						
LC-104	90	170	190	11	104	148	80	20	70	10	130	150	SRV5 - MSR5 - SSTR5 - STC
LC-104H						188	120						